

To help protect your floorcovering from varying levels of foot borne traffic and as the first defence against the weather, barrier mats must be installed at entry points to the building to limit the amount of wet and dry soiling. If maintained correctly, these barrier mats will limit the transfer of foot borne contamination and make the daily maintenance programme even easier.

**A slip resistant vinyl should never have an acrylic or metalised polish applied to its surface, as this will effect the slip resistant properties of the floorcovering.**

1. Allow at least 2 days from the completion of the installation of the Multisafe, prior to carrying out any wet cleaning.
2. Ensure that all trace of adhesive is removed from the surface of the Multisafe.
3. Scrub the surface of the Vinyl with Stride 1000 (Johnson Diversey) using a deck scrubber, a rotary scrubber or a scrubber-dryer standard speed machine fitted with medium brushes.
4. Mop area clean with hot water and allow to dry.

**Daily Cleaning**  
**Non Mechanical Method**

1. Clean floor area with a dust control mop.
2. Spray apply a solution of Carefree Stride 1000 (Johnson Diversey) diluted as per the manufactures recommendation. A pump-up spray will allow for even distribution and economy of the cleaning solution.
- 3. Carefree 2000 (Johnson) should be used on areas that are heavily soiled or greasy.**
4. Leave to stand for 5-10 minutes then agitate with a deck scrubber.
5. Mop area clean with hot water and allow to dry completely.

**Mechanical Method**

1. Clean floor area with a dust control mop.
2. Spray apply a solution of Carefree Stride 1000, (Johnson) diluted as per the manufactures recommendation. A pump-up spray will allow for even distribution and economy of the cleaning solution. **Carefree 2000 (Johnson) should be used on areas that are heavily soiled or are greasy.**
3. Leave to stand for 5-10 minutes.
4. Scrub the surface of the Vinyl using a rotary scrubber or a scrubber-dryer standard speed machine fitted with medium brushes.
5. Mop area clean with hot water and allow to dry completely.

**For the removal of Lime-scale (White film)**

Deposits of Lime-scale can be removed with an appropriate lime-scale remover, follow the manufacturers instructions carefully.